



**How to use NFC function on DS-K1T502DBFWX-C
with Hik-Connect Team mode**

Title:	How to use NFC function on DS-K1T502DBFWX-C with Hik-Connect Team mode	Version:	v1.0	Date:	09/09/2024
Product:	Access control	Page:	1 of 4		




Preparation

1. DS-K1T502DBFWX-C V1.9.1_240909 or above
2. Hik-Connect Team mode V6.6.301.0905 or above
3. NFC is available only for Android phones.

Step 1. Add K1T502 to Hik-Connect

- Enable Hik-Connect in the web configuration.


System and Maintenance – System Configuration – Network- Device Access – Hik-Connect.



Title:	How to use NFC function on K1T502 with Hik-Connect Team mode	Version:	v1.0	Date:	09/09/2024
Product:	Access control	Page:	2 of 4		




- Add K1T502 to the Hik-Connect, this can be done via QR Code, Manual, Local online devices, and import from personal devices.



Make sure the Device is online and has the correct time zone in the device management.

Step 2. Person Management and Access Levels on Hik-Connect

- Enter Access Level Management from Applications – Access Control. Create Access Levels for K1T502, with desired Access Schedule.




Title:	How to use NFC function on K1T502 with Hik-Connect Team mode	Version:	v1.0	Date:	09/09/2024
Product:	Access control	Page:	4 of 4		



Step 3. Enable NFC


- Enter Me – Door Opening Settings. Enable Open Door via NFC option.



Step 4. Test NFC

- Put the phone near the DS-K1T502 reader to automatically unlock the door via NFC. Verify device event log.

--	--	--	Door Open (Door Lock)	2024-09-15 11:46:30
4830182881	Ivaylo	--	Access Granted by NFC	2024-09-15 11:46:29
--	--	--	Door Closed (Door Lock)	2024-09-15 11:46:12
4830182881	Ivaylo	--	Access Granted by NFC	2024-09-15 11:46:07
--	--	--	Door Open (Door Lock)	2024-09-15 11:46:07



See Far, Go Further